

# Now SMS/MMS Android Modem

## Quick Start Guide

Using a GSM modem, or an Android phone as a modem, is a quick and efficient way to get started with SMS and/or MMS applications. No special service provider subscriptions are required, just a standard SIM card that has been activated for use with a mobile operator.

NowSMS controls the modem to send and receive SMS and MMS messages.

NowSMS allows end users to send and receive SMS and MMS messages via a web interface or their regular e-mail client.

NowSMS enables applications to send and receive SMS and MMS messages using standard protocols such as HTTP, SMTP/POP3/IMAP, SMPP or MM7, or using API examples for Java, PHP or command-line interfaces

NowSMS and NowSMS Lite support the ability to use Android phones as GSM modem devices for both sending and receiving SMS and MMS messages.

For most customers, using an Android phone as a modem is preferable to using a dedicated GSM modem device. These reasons include:

- **LTE Support** - LTE based Android devices can provide higher speed support for MMS sending and receiving.
- **Network Compatibility** - Some mobile operators (and modem device manufacturers) assume that modems are used for internet access only and disable SMS and/or MMS support for modems. This is not an issue for Android phones.
- **CDMA Support** - For years, US based customers have asked us about modems that can support Verizon and Sprint. Android phone support allows us to support those network operators using both CDMA and high speed LTE.
- **Broad Device Availability** - For customers interested in trying NowSMS, it is far easier to locate or acquire an Android device than a conventional modem.
- **MMS Performance** - With conventional GSM modems, MMS performance is limited by the mode switching required to switch between data and SMS channels. There are no mode switching delays mixing SMS and MMS traffic on Android devices.
- **Multiple Modems** - USB connectivity (and driver quality or lack thereof) is a major limitation for systems with multiple conventional GSM modems. For Android phones, the NowSMS server connects to the Android phones over WiFi or cellular data, providing far greater performance for NowSMS to simultaneously control multiple modems. Modems can even be located in different physical locations to maximize signal strength. (The NowSMS server communicates over WiFi or cellular data to an app running on the Android phone.)

## System Requirements

This document is intended to provide a quick start for setting up the Now SMS/MMS Gateway to use an Android modem for sending and/or receiving SMS and/or MMS messages. The configuration steps are similar in NowSMS Lite, however there is a separate Quick Start Guide available on the <http://www.nowsms.com> web site that contains instructions specific to that product.

1.) Android Phone running one of the following Android versions:

- 2.3 (Gingerbread)
- 4.0 or 4.1 (Ice Cream)
- 4.2 or 4.3 (Jelly Bean)
- 4.4 (Kit Kat)
- 5.x (Lollipop)
- 6.x (Marshmallow)
- 7.x (Nougat)

2.) WiFi or Cellular Data Connectivity for Android Device

3.) PC running Windows for NowSMS software. Supported versions of Windows include Windows XP, Windows Vista, Windows 7, Windows 8, Windows 10, Windows 2003 Server, Windows 2008 Server, and Windows 2012 Server. Server, workstation, 64-bit, 32-bit, business and home editions of these operating systems are supported.

## Supported SMS and MMS Message Types

SMS text message formats supported include all standard text formats, including long messages, Unicode characters and emoticons. (Other binary SMS formats, such as WAP Push, are not supported when using an Android device as a modem, and can only be supported by dedicated GSM modem devices. Message class attributes such as Flash are also not supported by the Android interface.)

MMS support may be limited by content types and size restrictions imposed by the mobile operator.

## Connectivity Options

The Android phone should be running an Android version between Gingerbread (2.3) and Nougat (7.x).

The NowSMS software runs on a Windows PC and will communicate with the Android device using TCP/IP.

There are 3 ways to configure this connectivity:

- 1.) **Local WiFi Mode** – The Android device is connected to WiFi and is on the same network as the NowSMS PC. When running on the same local network, the NowSMS PC and Android device can find each other without requiring manual IP address configuration.
- 2.) **Remote Direct Mode** – The Android device is configured to maintain a constant connection to the NowSMS server, using WiFi or cellular data. The NowSMS PC must be accessible via a static/fixed IP address or internet host name. If using WiFi on the Android device, the NowSMS PC can use a static IP on the same LAN. If using cellular data, the NowSMS PC must be accessible over the internet (or via a VPN, which is beyond the scope of this guide).
- 3.) **Remote via Cloud** – This is the easiest option if you are not familiar with, or do not wish to be concerned with networking requirements. The Android device and NowSMS PC both maintain a connection to a secure cloud service which establishes a secure and encrypted tunnel for communication.

## Important Notes About NowSMS & the Android Phone

Please note that after the NowSMS Modem software is installed on the Android Device, received SMS and MMS messages will be processed by NowSMS instead of the built-in messaging client.

It is possible to configure NowSMS in a send only mode to prevent this, but it is important to note that the NowSMS software assumes that in most configurations, NowSMS will be the only application processing SMS and MMS messages on the device.


Of course, the NowSMS Modem software can be easily removed or temporarily stopped to allow other standard applications to again process messages.

It is also important to note that the NowSMS Modem software will cause the battery of the Android device to be used more quickly. This is because NowSMS keeps WiFi and/or a data connection active, so that the device is available when messages need to be sent out. In most configurations, it is expected that the Android phone will be connected to a power source at all times.

## Installing NowSMS Modem on the Android Phone


**Step 1:** The settings on the Android Device must be configured to allow applications from unknown sources, so that the application can be downloaded from the NowSMS web site.

Go into **Settings** on the phone, look for **Unknown Sources** under **Security Settings**. Menus will vary in different versions of Android, and with different vendor implementations.




Android will display a caution message about the security implications of installing applications that have not been verified by Google. This setting must be accepted to enable the setting.

We recommend that the Android phone running the NowSMS Modem software should be dedicated to that task and not be used for other applications, to minimize the risk of enabling this setting. This setting may be disabled after the NowSMS Modem application is installed.



**Step 2:** Open the web browser or Chrome and go to the download page on the NowSMS website: <https://www.nowsms.com/download>

Scroll down to locate the download link for the NowSMS Modem App.




Some versions of Android will warn that this type of file may be harmful and require you to select OK before downloading the application.

The NowSMS Modem App is contained in a file named NowSMSModem.apk.

Most recent versions of Android will display a link to open this file.

If the open link does not work, or no option to open the app is displayed, the easiest way to locate the download is to swipe down from the top of the screen where it will be shown in system notifications. Press on the notification to begin the install.





If the download does not appear as a notification, go to Applications and use the Downloads app to locate NowSMSModem.apk.


### Step 3: Install NowSMSModem.apk

Complete the installation of NowSMSModem.apk by allowing the requested privileges.

It may be necessary to press Next or scroll down before the Install option is presented.









Open the App after it is installed.

**Step 4:** Configure NowSMS Modem by opening the application. The default settings assume the device is using WiFi to connect to NowSMS on the same Local Area Network.

Other connectivity options require additional setup on the NowSMS server, and are discussed later in this document.



We recommend configuring the Device Name setting to a name appropriate for your installation. The default Device Name is the phone number, if it is available from the network. Some networks do not allow the phone number to be read by applications. In those instances, the Device Name will default to an Android unique device identifier.

Press **Settings** to change the Device Name, and then press **Save**.



**Step 5:** On most Android devices (4.4/KitKat and later), an additional settings button will be displayed: **Hide Messages from SMS App**.

By default, on these versions of Android, SMS messages sent or received by NowSMS modem will be logged in the messaging database on the device. This may cause performance or storage issues. This button installs NowSMS Modem as the default messaging application and disables this logging.



**Step 6:** The Android phone is now ready to be connected to a NowSMS installation. Note that the messages received counter will display “(not enabled)” until a PC running NowSMS has been configured to receive messages from this modem.


## Installing NowSMS on a Windows PC


A fully functional, but time limited, trial version of NowSMS can be downloaded from the NowSMS web site at <https://www.nowsms.com/download-free-trial>.



Run nowsms.exe to install or update the Now SMS/MMS Gateway software.



The installation requires administrative privileges on the Windows system and Windows will display a warning about administrative privileges before installing the application.


The default installation settings are acceptable for most installations, and the sequence of installation prompts should resemble the following. The button that must be pressed to continue is highlighted in the following images.














When the installation is finished, NowSMS may again display a prompt about the number of days remaining in the trial license. Press OK to continue.



## Configuring NowSMS

Configure NowSMS to use the Android device by adding an SMSC connection.






There are 3 ways to configure the connectivity between NowSMS and the Android device:

- 1.) **Local WiFi** – The Android device is connected to WiFi and is on the same network as the NowSMS PC. When running on the same local network, the NowSMS PC and Android device can find each other without requiring manual IP address configuration.
- 2.) **Remote Direct** – The Android device is configured to maintain a constant connection to the NowSMS server, using WiFi or cellular data. The NowSMS PC must be accessible via a static/fixed IP address or internet host name. If using WiFi on the Android device, the NowSMS PC can use a static IP on the same LAN. If using cellular data, the NowSMS PC must be accessible over the internet (or via a VPN, which is beyond the scope of this guide).
- 3.) **Remote via Cloud** – This is the easiest option if you are not familiar with, or do not wish to be concerned with networking requirements. The Android device and NowSMS PC both maintain a connection to a secure cloud service which establishes a secure and encrypted tunnel for communication.

## Local WiFi Mode

In **Local WiFi** Mode, the Android device is connected to WiFi and is on the same network as the NowSMS PC. NowSMS will query the local network to locate Android devices with the NowSMS Modem application loaded, and they will be displayed in a list. It may take up to 60 seconds for NowSMS to locate the device.

Select the device and press **Add Modem**.



In some cases, NowSMS may not be able to find the Android device. Possible reasons for this include:

- 1.) NowSMS and the Android device might be connected to different access points which create separate networks and are not bridged.
- 2.) The wireless access point may have **isolation mode** enabled (very common on guest networks), which prevents devices from communicating with each other.

In situations where the devices cannot communicate locally, Remote via Cloud connectivity should be considered as an alternative.

When the NowSMS server confirms that it has connected with the device, it will display the device connection properties. Press OK to save the configuration.

Android Modem Connection

Connection Type: ☒ Local ☐ Remote ☐ Cloud

NowSMS Route Name:

Phone Number:

☒ Receive SMS Messages

Route SMS to local user:

☒ Send MMS Messages

☒ Use Default MMS Settings

MMS Server URL:

MMS Proxy (if required):

☒ Receive MMS Messages

Routing


☒ Support any outbound message traffic

NowSMS will prompt to ask if a test message should be sent via the modem. Select **Yes** and enter a phone number to receive the test message when prompted.

## Remote Direct Mode


In **Remote Direct Mode**, the Android device is configured to maintain a constant connection to the NowSMS server, using WiFi or cellular data. The NowSMS PC must be accessible via a static/fixed IP address or internet host name. If using WiFi on the Android device, the NowSMS PC can use a static IP on the same LAN. If using cellular data, the NowSMS PC must be accessible over the internet (or via a VPN, which is beyond the scope of this guide).


To configure this mode, assign a device name and secret to be used by the device.




When you press **Add Modem**, NowSMS will begin waiting for the device to connect on TCP port 8990.

NowSMS might prompt to confirm starting service processes with the following prompt:





On the Android Device, under **Settings**, configure the matching **Device Name** and **Shared Secret**. For **NowSMS Server**, provide an IP Address or Internet host name for the device to use when connecting to the server.



When the NowSMS server confirms that it has connected with the device, it will display the device connection properties. Press OK to save the configuration.

Android Modem Connection

Connection Type: ☐ Local ☒ Remote ☐ Cloud

Shared Secret:

NowSMS Route Name:

Phone Number:

☒ Receive SMS Messages

Route SMS to local user:

☒ Send MMS Messages

☒ Use Default MMS Settings

MMS Server URL:

MMS Proxy (if required):

☒ Receive MMS Messages

Routing


☒ Support any outbound message traffic

NowSMS will prompt to ask if a test message should be sent via the modem. Select **Yes** and enter a phone number to receive the test message when prompted.


## Remote via Cloud Mode

**Remote via Cloud** mode is the easiest option if you are not familiar with, or do not wish to be concerned with networking requirements. The Android device and NowSMS PC both maintain a connection to a secure cloud service which establishes a secure and encrypted tunnel for communication.


To configure this mode, first assign a device name and secret to be used by the device.




When you press **Add Modem**, NowSMS might prompt to confirm starting service processes with the following prompt:







NowSMS will connect to the cloud service to acquire a unique Cloud Server ID. On the Android Device, under **Settings**, configure this **Cloud Server ID**, along with the **Device Name** and **Shared Secret**.



When the NowSMS server confirms that it has connected with the device, it will display the device connection properties. Press OK to save the configuration.

The screenshot shows the 'Android Modem Connection' dialog box with the following configuration:


- Connection Type:** ☐ Local ☐ Remote ☒ Cloud
- Shared Secret:**
- NowSMS Route Name:**
- Phone Number:**
- ☒ **Receive SMS Messages**  
**Route SMS to local user:**
- ☒ **Send MMS Messages**
- ☒ **Use Default MMS Settings**
- MMS Server URL:**
- MMS Proxy (if required):**
- ☒ **Receive MMS Messages**
- Routing**
  - ☒ **Support any outbound message traffic**
  - 
  -

At the bottom are  and .


NowSMS will prompt to ask if a test message should be sent via the modem. Select **Yes** and enter a phone number to receive the test message when prompted.

## NowSMS Web Interface

To access the NowSMS web interface, it is necessary to define account credentials. This is done by creating an SMS user account in the NowSMS configuration (under **SMS Users**). These account credentials can be entered when accessing the web interface at <http://localhost:8800> or <http://127.0.0.1:8800> from a web browser on the same system.



The screenshot shows a web browser window with the address bar displaying <http://127.0.0.1:8800/LOGIN>. The page title is "NowSMS Login". The interface features a dark blue header with "Send Message" and "Settings" dropdown menus, and the "now.sms" logo. A light blue login box is centered on the page, containing the title "NowSMS Login", two input fields for "User Name:" and "Password:", and a "Login" button.



The screenshot shows a web browser window with the address bar displaying <http://127.0.0.1:8800/>. The page title is "NowSMS Send Text". The interface features a dark blue header with "Message Type", "Admin", and "Settings" dropdown menus, and the "now.sms" logo. A light blue "Send Text Message" box is centered on the page, containing a "Logout" button and several input fields: "To:", "Sender:", "Message Route:" (with a dropdown menu set to "default"), "Text:" (with a large text area), "Delivery Receipt:" (with radio buttons for "Yes" and "No", where "No" is selected), and "Delayed Delivery:" (with a text input field and a note "(Format: yyyy-mm-dd hh:mm)"). A "Send Message" button is at the bottom.